MD-LIVE

Mobile Data Extraction and Analysis Tool for on-the-spot investigation and triage

MD-LIVE supports quick on-site investigation with device scanning, extraction, analysis, and reporting features. Selective extraction, Watch List, Keyword, and Hash search features enable time-efficient investigation and prevent privacy infringement.

N	fobile Evidence Analysis Program	SAMSUNG SM-S9010 Android 12 NOSE	eriod to Investigate : Entire				2 🗟 # 🕏 i 🛈 – 🕫
E	Select App	App List					0
Th	ird-party Apps	Watch List Support Down					Manage Watch List Add App Fille
Q	Search	A Basic Data					
Sele	ection Range	🗆 💮 Browser	🗆 🔄 Call History	🗆 🔀 Email	🗆 🔡 Media Log	🗆 🧙 Message	🗆 🛜 Network Log
Ŀ	Select All Apps High Priority	Notes	C 12 Schedule	System Info	Contacts (Automatic check when analyzing	Etc	Map History
E	Low Priority	A 🗌 Media Data	_	_	messages)		
Fib	e	Documents	Picture	Sound	🗆 🕨 Video		
	raction Only	A Messenger					
Has		🗆 🙊 KakaoTalk	🗆 😋 in 👁	🗆 🐣 qq	🗆 😪 Telegrem	🗆 🥵 Viber	🗆 馣 Wechet 👁
spe Veri	speed. Verification is performed based on added hash sets. PhotoDNA	🗆 🥵 WhatsApp 👁					
		A Social					
	sing PhotoDNA can take some time. raction Options	E Facebook	🗆 🛂 Taritar	🗆 💽 Instagram			
	 App data may be deleted or changed. The App Version and Installation history may be different from that of the actual device. Reinstalled apps may not run. App ministallation may fail. E an app has chappeared from the device, use 	4 🗌 Call					
- Th be o		🗌 📄 Google Duo	🗆 🚗 ino				
- Ap - Ha		I Browser Ensure data will not be preserved for longer than a certain paried of time.					
(Do	vergrade App Restore] to restore the app.	🗆 🧑 Orone					
		- Cloud					
		C 🙆 Microsoft OneDrive					
		и 🗌 Мар					
		🗆 🔀 Google Map					
		🖌 🗌 Tool					
		Eisby	🗆 Ġ Google	Microsoft Apps	Personalization Service Client	Samcung Experience Service	Sameung Finder
		🗆 📄 Samsung One UI Home	Samsung Software Update	🗆 📄 Samsung Tags			
		4 Eile					

System Requirements

OS	Windows 8/10/11 (64 bit)				
CPU	i5 or above				
RAM	8GB or above				
Disk	256GB or above				
Display	1200x700 or above				
USB	2 or more USB 2.0/3.0/3.1 ports				
Microsoft.Net Framework 4.6.2					

Product Components

MD-LIVE Installation Software (HDD/USB Memory/Online) USB Dongle Key 1 EA Warranty 1 Year

Hardware Package Option (MD-PORTABLE)

Rugged case Laptop or Tablet Cable sets HDMI Capture board MD-CAMERA (External HD Camera)

Product Specification

Extraction

- Automatic recognition of smartphone model
- Detail information view for installed apps
- Various filtering option for installed apps
- Extraction guides and notifications per OS type
- Display of extraction progress by app
- Multi-space notification
- Selective extraction by apps or by time period
- Selective mode of Scan, Extraction, Analysis flexible to on-site use cases
- Notification of the battery level at the device before extraction

Analysis

- App analysis
- Over 2,000 Android and iPhone smartphone apps
- Messenger data decryption Facebook Messenger, WeChat, Signal, Wickr, Discord etc.
- Multi-account app analysis WeChat, Telegram, Instagram, Facebook Messenger etc.
- Various DB format analysis: SQLite, Realm, Bolt, ESE etc.
- Various filesystem analysis
- Signature-based multimedia analysis

Analysis Result View

- Customized filters by analysis result types
- Ability to view selected items or search results
- Messenger view
- GPS geolocation visualization support with the online and offline maps
- Keyword list search by import of external file or manual input
- Supports Watch List and the user-defined filter of Apps in Watch List
- Hash Sets search by import of external file, manual input, Project VIC(UK, US, CA), Photo DNA
- Internal viewers for documents, database, Hex, text, image, audio and video
- Browser for Internet browsing history view

Recording Investigation

- Photographing, video/audio recording of evidence and investigation process by MD-CAMERA (External HD Camera) or HDMI capture board supplied as option items
- Mirrored and remote-controlled smartphone screen can be captured and recorded
- PC screen recording of MD-LIVE to reproduce or to verify its forensic process
- Log analysis to track the recent history of smartphone app usage and system history
- Monitoring active phone process for malware or specific active app investigation

Reporting

- Report types

- Analysis results summary summarized result
- Analysis results report detail result
- Electrically stored information extracted files list
- Report options
- Anonymous reporting to protect the witness or the victim by hiding owner information
- Large image reporting to display one image on each page not to scales down
- Archive report file as MDF/ZIP/TAR/DD
- Report file format PDF, Excel
- HASH algorithms options MD5, SHA1/224/256/384/512, RIPEMD128/160/256/320

